

User instruction number: UI_PRK-1

Gælder for følgende modeller: Applies to the following models: Gelten für die folgenden Modelle:

Tarpaulin EMG tool bags



 Brugsanvisning Instruktioner for patch repair kit	N/A
User instructions Instructions for patch repair kit	pages 2-4



Gebrauchsanleitung

Richtlinien für die Patch Repair Kit

N/A

User Instructions for: Patch Repair Kit for tarpaulin EMG lifting bags

List of parts:

EMG

Description	QTY	Picture
Pencil case	1	
SABA sabacontact 70 T - 250 ml	1	
Tailor chalk	5	
0.75 mm tarpaulin - Orange - Ø10 cm	10	
0.75 mm tarpaulin - Orange - Ø15 cm	10	
0.75 mm tarpaulin - Orange - 10x18 cm	5	
0.75 mm tarpaulin - Black - Ø10 cm	5	
0.75 mm tarpaulin - Black - Ø15 cm	5	
0.50 mm tarpaulin - Yellow - Ø10 cm	5	
0.50 mm tarpaulin - Yellow - Ø15 cm	5	

General notes:

- Do not use the tool bag if there is any doubt of the integrity of the bag. If ever in doubt, do not risk deeming the bag usable. Safety first.
- Only patch holes and small cuts.
- These patches only work on tarpaulin bags.
- The usual precautionary measures are to be adhered to when handling chemicals.
- Use proper safety equipment equipped.

ENGLISH



» Recommended filter: Filter AX

- 3
- » Review the bag and identify the hole/cut which needs to be patched.
- » Evaluate the patch size needed.
- » Pretreat PVC material with cleaner.
- Sufaces must be dry and free for dust.



- » The patch must cover the entire hole/cut.
- » The patch must have at least 1 cm free space from the hole to the outer edge.



- » Place the bag on the ground, a table or another flat surface.
- » This will make it easier to apply pressure and straighten out the fabric.

UI_PRK-1





- Place the patch on the bag and draw around with a grease pen or chalk to highlight the area.
- This will give you an easy reference point when applying the glue

Apply glue to the entirety of the marked area on the bag. Apply glue to the entire area of the patch. One side only.



- » Attach the patch on the bag.
- » Apply a lot of pressure.
- » The patch must be fully attached all the way around.



- » When the patch is attached, a drying time of at least 15 minutes is required.
- » Do NOT use the bag during this time.
- » It may be an idea to put pressure on the patch during this time, by placing something heavy on top.



- » Test the strenght of the patch and fabric.
- » Make sure the patch is still fully attached all the way around.
- » The bag is now usable again.

X





- » The patch must NOT be used on polyester bags.
- » The patch will only attach correctly on tarpaulin bags.