



4467-100 / Replaceable plastic buckle



COLOR:



50 G

- Changeable 50 mm buckle in sturdy plastic.
- **Material (main):** Plastic
- **Material (screw/pin):** Stainless steel
- **Fits model(s):** 4467, 5618
- If any of the buckles on your 4467 breaks, this buckle can easily replace it.
- No need for sewing - all you need is a screwdriver to tighten the screws.
- It is attached by a pin and screw which means it is easy to mount without having to damage or modify the ribbons on the bag.
- Tip: Loctite can be used to further prevent the screw from coming loose.
- Fits 50 mm ribbon.
- Side release function.

