





BU50 (former 4467-100) / Replaceable plastic buckle







■ Changeable 50 mm buckle in sturdy plastic.

Material (main): Plastic
Material (screw/pin): Stainless steel
Fits model(s): 4467, 5618

- If any of the buckles on your 4467 breaks, this buckle can easily replace it.
- No need for sewing all you need is a screwdriver to tighten the screws.
- It is attached by a pin and screw which means it is easy to mount without having to damage or modify the ribbons on the bag.
- Tip: Loctite can be used to further prevent the screw from coming loose.
- Fits 50 mm ribbon.
- Side release function

